



CREATOR

31048



[LEGO.com/creator](https://www.lego.com/creator)

1



2





3



4











1x

1






2





2x

3






1x



4x

4






1x



2x

5





1x




1x



3x

6







1x



1x

7






1x



1x

8





1x



1x



1x



3x



1x

9






1x

10





4x



2x

11





1x



1x

12





1x




2x



2x

13





14





2x



3x




1x





1x

15






16






1x

17



2x


18






1x

19



1x

20




2x



1x

21



1x




1x

22





23







24







25



2x


2x

2x

26



2x





1x



1x

27





3x



3x

28



3x



1x



1x



1x

29

1



2





1x



5x



2x

30





2x



1x

31





2x



2x

32





1x




1x



2x

33





2x



1x

34





1x



1x

35





1x



1x

36






1x



1x



1x



37





6x



4x




4x




4x

38


1




2




3



4



5



2x





6x



4x




4x




4x

39

1




2




3



4



5



2x






3x



3x



3x

40





1x



1x




1x



41






4x




8x

42





43





1x



1x

44






1x



1x



1x



45






1x



1x



1x



46





1x







1x

47




48






49







50





51





52





2x



2x



2x

1




2



3



4



53




1x

4x

2x

54





55





1x



1x



1x



1x

56

1




2



3





57





1x



2x



2x

58





2x

59





1x



2x



1x



2x



2x

60





2x



2x

61





1x



1x



1x



1x



2x



62





2x



3x

63





1x




2x



1x

64





65





2x



2x

66





3x



2x



67






68

1



2




3




4



5



6







1x



1x



1x



1x



1x

69


1



2



3



4







1x



2x



1x



1x




2x

70




2x





2x

71



1x

72






2x

73



2x

74





2x

75



1x

76





2x

77



78



1x

78





2x





1x

79

1



2



4x




4x



4x

80


1



2




4x








1x

81





82







4x
4211190



11x
4211225



2x
4579690



4x
4211186



2x
4655611



4x
4263776



1x
4222627



6x
4211183



1x
6075208



1x
4211221



2x
4264755



1x
6047037



4x
6102975



6x
4211220



3x
4211152



23x
4216581



4x
6080355



1x
6069984



1x
6102360



1x
4211166



7x
4211149



20x
4211150



1x
6035547



13x
4211242



20x
4225469



1x
6037289



1x
459926



2x
4517925



1x
474026



1x
452826



2x
302126



1x
6081988



1x
4533771



1x
6079894



4x
403226



4x
6056234



4x
614126



3x
4598528



2x
300426



1x
383526



2x
4222960



6x
4183133



2x
4568387



2x
6006126



1x
4547489



2x
4632566



1x
4119410



1x
6116602



1x
6021844



2x
302324



1x
6012442



1x
4140587



1x
302224



1x
4599537




2x
4650500




2x
3006840



1x
6112751



3x
4536998



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :

