

The LEGO logo is displayed in its characteristic white font with a black outline, set against a red rectangular background.The Disney Princess logo is presented in a stylized, cursive font within a pink, ornate banner that has a scalloped edge.


41065



WARNING: CHOKING HAZARD.
Small parts. Not for children under 3 years.



[LEGO.com/disneyprincess](https://www.lego.com/disneyprincess)











AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.
Contient des petites pièces. Ne convient pas aux enfants de moins de 3 ans.




ADVERTENCIA: PELIGRO DE ASFIXIA.
No recomendado para niños menores de 3 años. Contiene piezas pequeñas.









1




2





3





1x



1x

4






1x



1x

5







1x





1x

6





7





1x



1x



1x

8






1x



2x

9





1x



2x

10






2x



1x

11





1x



1x


12





1x

13





3x



1x

14





1x




1x

15



16







1x




1x

17





18






4x

19






1x


20

1



2






21





2x

22





1x

23





1x




1x




1x

24

1



2





2x

25






2x

26







27





1x

28





2x



2x



2x



2x

29


1



2



2x





1x



2x

30





2x

31





1x

32






2x

33





34





1x



1x

35





1x



1x



1x

1



2



36






1x




1x




1x



1





2






2x

3




1x

4






2x



1x


5





2x

6





1x





1x





1x

7






8







1x

9






10





2x


11





2x

12





1x



1x




1x

13

1



2





1x




1x



2x

14





1x




1x


15

1




2






16




17





2x

18







1x



1x


19





1x


20






2x

21



22








23

1




2





5




24




25






26





2x

27





1x

28







2x
6109814



3x
6055875



1x
6163405



1x
6150155



1x
6134260



1x
4523159



1x
4529247



1x
6092594



1x
6093529



1x
6057986



1x
4569385



4x
4656783



1x
6097042



1x
6134346



1x
306224



2x
287724



3x
614126



1x
452826



1x
4107050



1x
306228



2x
374128



2x
242328



2x
6133767



2x
383228



1x
4273743



1x
6112751



4x
4163917



1x
4567333



1x
3005749



6x
4183133



1x
4187743



2x
4537936



9x
6078932



1x
4222960



1x
4624184



1x
6047551



3x
4216581



2x
4620075



6x
4211180



1x
6102360



1x
4495724



2x
6069984



2x
4277016



4x
4216695



4x
4211221



1x
4211186



2x
4221590



2x
4650260


2x
6136412


1x
4621545


1x
4517992


1x
6096990


1x
6055645


2x
6153180


3x
4566607


1x
6015344


2x
4211614


1x
4211410


1x
6108913


2x
4613256


1x
4278271


1x
302301


1x
4624989


1x
306801


1x
302201


1x
366601


1x
303401


1x
6151534


1x
4650647


2x
4523145



2x
4109995


3x
4159279


1x
4113917


1x
4118866


2x
4185273


1x
6100579


1x
6150169


1x
6062386


1x
4619512


1x
4619516


1x
4651902


1x
6133352


1x
4649745


2x
6074906



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial


: 00800 5346 5555
: 1-800-422-5346

LEGO

Friends⁺

41126



41125

41123



■ 41126



■ 41125



■ 41123

LEGO.com/friends

LEGO

Disney
PRINCESS

41055



41062



41067



41063



41068



41065



41061



41066



Disney
FROZEN

Disney
REINE
NEIGES

Disney
FROZEN
CORONA



Disney PRINCESS



41141

41140

41069

41142





LEGO.com/disneyprincess