



CITY

60277





- 1** Scan the code on the front cover
 Scanne den Code auf der Titelseite
 Scanne le code sur la page de couverture
 Scanner le code sur la page couverture
 Scansiona il codice sulla copertina
 Escanea el código de la portada
 Faz scan do código na frente da capa
 Olvasd be a borítón látható kódot!
 Noskeně kodu uz priekšējā vāka
 扫描封面上的二维码







- 2** Get Instructions PLUS
 Hol dir Instructions PLUS
 Obtens les instructions PLUS
 Obtenir les Instructions PLUS
 Scarica Instructions PLUS
 Descubre Instructions PLUS
 Obtém Instruções PLUS
 Szerezd be az Instructions PLUS kiegészítőt!
 Saņem "Instructions PLUS"
 获取更多说明




LEGO.com/apps



Check for compatibility
 Kompatibilität prüfen
 Vérifier la compatibilité
 Controlla la compatibilità
 Comprueba tu compatibilidad

Verificar a compatibilidade
 Ellenőrizd a kompatibilitást
 Pārbaudīt saderību
 检查兼容性













1x


1



2x


2






2x



3




8



4




5





1x


6






2x

7



1x


8





2x

9









1x




1x


10







1







2




3








1x

4






5




6





2x


7






1x


8





2x

9







10







11




12





2x

13



22





2x




1x

14



1x

15






2x



2x


16






2x

17



2x


18








2x

19








20





21







22







23




24







25



30

26







CITY ADVENTURES

City Abenteuer
Aventuras en City
City Aventuras
City kalandok
City piedzivojumi
乐高城市大冒险



VITO
60242



SAM
GRIZZLED
60243



SNAKE
RATTLER
60243 • 60276



ROOKY
PARTNUR
60244



FRANKIE
LUPELLI
60244 • 60277



TOM
BENNETT
60245



BIG
BETTY
60245



WHEELER
60246



DAISY
KABOOM
60246



CLARA
THE CRIMINAL
60276



GRACIE
GOODHART
60277



DUKE
DETAIN
60242 • 60246 • 60276



FREYA
MCLOUD
60248 • 60280



CLEMMONS
60247 • 60281



BOB
60282



FELDMAN
60282



TREAD
OCTANE
60258



HARL
HUBBS
60258 • 60266



SHIRLEY
KEEPER
60292



MADISON
60292

CITY

ADVENTURES

City Abenteuer
Aventuras en City
City Aventuras
City kalandok
City piedzīvojumi
乐高城市大冒险

Aus der erfolgreichen TV-Serie!
Vu dans la série télévisée à succès !
Dalla divertentissima serie TV!
¡De la popular serie de la tele!
Da série de sucesso da TV!
A népszerű TV-sorozatból!
No populārā TV seriāla!
源自热门动画片!



FROM THE HIT
TV SERIES!



CITY



60277



60275



60276